



## **Turbo Supercharger Installation Instructions**

The Turbo Supercharger unit is installed between the air filter and throttle body.

- Location of installation: Install the product between the air filter and the throttle body, into the middle of air inlet pipe.  
(Propeller side face to the air filter) timal location: Install the product 10 cm to 30 cm in front of the inlet throttle body.
- Optimal location: Install the product 10 cm to 30 cm in front of the inlet throttle body.
- When the inlet pipe is curved, you can install the Turbo Supercharger into the middle of dual bend pipe.
- If the car is equipped with air flow sensors (AIF), install the Turbo Supercharger before or after AIF with the same size.  
When there is minor difference in size, you can wrap a few rounds of tape on outer rim.
- The products can be installed to petrol or diesel cars, as long as there is the inlet pipe on the air inlet of the throttle.

A jubilee clip (not included) is recommended to secure the Turbo Supercharger inside the intake hose. Also if your hose has a diameter greater than 65mm you must custom fit the Turbo Supercharger using a silicone hose. This is a universal and will fit any car.